



Southeastern Aluminum Products, Inc.

Telephone: 904-781-8200 • Post Office Box 6427 • Jacksonville, Florida 32236-6427

INSTALLATION INSTRUCTIONS **CRYSTALLINE FRAMED BY-PASS DOOR**

IMPORTANT: Read all instructions carefully and become familiar with all parts before installation.

STEP 1 Sill track (A) is over-cut. Measure opening for sill track and cut 7/8" less than measurement to allow for wall jambs (B). Position sill track on curb with the low side to the inside of the shower. Leave equal space at each end.

STEP 2 Place wall jambs in vertical position over sill track and press all the way down (short legs to wall). Using a level to plumb each wall jamb, mark and drill holes for plastic anchors (E) using a 3/16" masonry bit. For fiberglass and acrylic stalls, use a 1/8" bit. Fasten jambs with #8 x 1 1/2" panhead screws (F). Orient the bumpers (P) so that the inside panel will pocket into the wall jamb closest to the shower head and attach using #6 x 3/4" panhead screws (N).

STEP 3 Header (D) is over-cut. Measure for header and cut 1/16" less than opening. Place header down on top of wall jambs (B).

STEP 4 To set tempered glass panels (G) in place, lift the inside panel inserting rollers into header (D) and lower into place. Next lift outside panel in place, being sure bottom of panel is inside sill track (A), and insert rollers into header. If either panel needs to be adjusted for plumb, remove from header and move roller position in hanger bracket until panel is square with jamb.

Note: If unit is made with obscure glass, orient panels so that the smoother side of glass is to the inside of unit.

STEP 5 Insert sill guide (H) into the slot on sill track dam and position in center of track (A). Align panels (G) inside guide. Secure guide with # 6 x 3/8" self drilling TEK screws (C). **IMPORTANT: DO NOT OVERTIGHTEN.**

STEP 6 Insert forked ends of towel bar brackets (K) into open ends of towel bars (J). Using the finger pulls provided (L), position towel bar assembly on panel and attach with #4-40 X 3/4" screws (M). The finger pulls are installed on the panel edges that pocket into the bumpers.

Note: The forked ends of the brackets may be spread slightly to ensure a snug fit.

STEP 7 Caulk all edges and joints exposed to water including where ends of sill track meet interior surface of wall jambs using a silicone based caulk or other suitable sealant that will prevent water leakage.

PARTS LIST

A	Sill Track with Vinyl Insert	1	H	Sill Guide	1
B	Wall Jamb	2	J	Towel Bars	2
C	# 6 x 3/8" TEK Screws	2	K	Towel Bar Brackets	4
D	Header	1	L	Finger Pulls	2
E	Plastic Anchors	6	M	# 4 x 3/4 Trusshead Screws	8
F	#8 x 1 1/2" Panhead Screws	6	N	# 6 x 3/4 Panhead Screws	2
G	Panels	2	P	Bumpers	2

